ULTRA JAZZ WIRING 2 Volumes, 2 Tones



For each pickup, solder the black&white wires together and tape up each connection.

Note: Tailpiece should be connected to common ground. All grounds 上 must be connected.

Copyright (C) 2003 DiMarzio, Inc. All rights reserved